


INSTRUCTION MANUAL



756 and 757 Ratchet Cable Cutters



Read and understand all of the instructions and safety information in this manual before operating or servicing this tool.

Register this product at www.greenlee.com

Table of Contents

Description	2
Safety	2
Purpose of this Manual	2
Important Safety Instructions	3
Specifications	4
Operation.....	4
Maintenance.....	5-7
Illustration	8
Parts List	
756.....	9-10
757.....	11-12

Description

The Greenlee 756 and 757 Ratchet Cable Cutters are non-insulated tools.

- The 756 is intended to cut copper and aluminum cable up to 1500 kcmil.
- The 757 is intended to cut ACSR up to 954 kcmil and 1/2" soft steel rod.

Safety

Safety is essential in the use and maintenance of Greenlee tools and equipment. This instruction manual and any markings on the tool provide information for avoiding hazards and unsafe practices related to the use of this tool. Observe all of the safety information provided.

Purpose of this Manual

This instruction manual is intended to familiarize personnel with the safe operation and maintenance procedures for the Greenlee 756 and 757 Ratchet Cable Cutters.

Keep this manual available to all personnel.

Replacement manuals are available upon request at no charge at www.greenlee.com.

All specifications are nominal and may change as design improvements occur. Greenlee Textron Inc. shall not be liable for damages resulting from misapplication or misuse of its products.

KEEP THIS MANUAL

IMPORTANT SAFETY INFORMATION



SAFETY ALERT SYMBOL

This symbol is used to call your attention to hazards or unsafe practices which could result in an injury or property damage. The signal word, defined below, indicates the severity of the hazard. The message after the signal word provides information for preventing or avoiding the hazard.

⚠ **DANGER**

Immediate hazards which, if not avoided, **WILL** result in severe injury or death.

⚠ **WARNING**

Hazards which, if not avoided, **COULD** result in severe injury or death.

⚠ **CAUTION**

Hazards or unsafe practices which, if not avoided, **MAY** result in injury or property damage.



⚠ **WARNING**


Read and understand all of the instructions and safety information in this manual before operating or servicing this tool.

Failure to observe this warning could result in severe injury or death.



⚠ **WARNING**

Electric shock hazard:
This is not an insulated tool. Contact with live circuits could result in severe injury or death.



⚠ **WARNING**

Wear eye protection when using or servicing this tool.
Failure to wear eye protection could result in serious eye injury from flying debris.



⚠ **WARNING**

Keep hands away from the blades and sprocket.
The spring-loaded mechanism could close unexpectedly, resulting in personal injury. Disengage the spring before servicing this tool.




⚠ **CAUTION**

- This tool is intended for two-handed operation. Maintain a firm grip on both handles when using this tool. Using this tool in any other manner can result in injury or property damage.
- Inspect before use. Replace any worn or damaged parts. A damaged or improperly assembled tool can break and strike nearby personnel.
- Do not perform any service or maintenance other than as described in this manual. Injury or damage to the tool may result.
- Do not exceed the rated cutting capacity of this tool. The tool may break and cause injury or property damage.

Failure to observe these precautions may result in injury or property damage.


Specifications

756 Ratchet Cable Cutter



Weight.....	4.5 kg (10 lb)
Length.....	69.85 cm (27.5")
Jaw Opening	5.08 cm (2")
Maximum Capacity.....	1500 kcmil (630 mm ²) Copper/Aluminum

757 Ratchet Cable Cutter




Weight.....	5.2 kg (11.5 lb)
Length.....	74.3 cm (29.25")
Jaw Opening	30 mm (1.18")
Maximum Capacity.....	954 kcmil ACSR, 1/2" (12.7 mm) soft steel rod

Operation

1. Grip both handles firmly.
2. Pull the handles apart to open the blades.
3. Place the wire between the blades.
4. Allow the chain spring to close the blades while keeping a firm grip on the handles.
 - Standard cutting: To cut smaller wire, press the handles together.
 - Ratchet cutting: To cut larger wire, use the ratchet by opening the shorter handle until it clicks once. Close the handle until it clicks once. Repeat this ratcheting process until the cut is complete.
5. Open the handles completely to release.

Maintenance

	⚠ WARNING
	<p>Keep hands away from the blades and sprocket.</p> <p>The spring-loaded mechanism could close unexpectedly, resulting in personal injury. Disengage the spring before servicing this tool.</p>

General

- Keep grips clean and dry.
- Keep the blades sharp. If the cutting surfaces are chipped or nicked, sharpen or replace the blades.


Lubricate the blades

1. Clamp the long handle into a vise.
2. Grip the short handle and open the cutter.
3. Apply a light film of B-2 Moly grease or an equivalent over the blades with a small brush.
4. Close and open the cutter several times to spread the lubricant.

Clean and lubricate the internal parts

1. Disassemble the cutter (refer to the disassembly instructions in this manual).
2. Clean the parts with solvent.
3. Apply Mobilgrease® Special 53030-3 or an equivalent to each moving part.
4. Reassemble the tool.

Clean the cutter mechanism

	⚠ WARNING
	<p>Wear eye protection when using or servicing this tool.</p> <p>Failure to wear eye protection could result in serious eye injury from flying debris.</p>

Use compressed air to blow dirt and foreign particles out of the ratchet mechanism.

Disengage the Spring

1. Clamp the long handle (31) into a vise with the short handle (53) parallel to the floor and with the head pointing away from you.
2. Remove the rubber grip (43).
3. Unhook the spring (39) from the pin (40) in the short handle (53) (see Figure 1).




Figure 1

Disassembly

1. Clamp the long handle (31) into a vise with the short handle (53) parallel to the floor and with the head pointing away from you.
2. Remove the rubber grip (43).
3. Unhook the spring (39) from the pin (40) in the short handle (53) (see Figure 1).
4. Loosen nut (20) from bolt (19) using 7/16" wrenches.
5. Remove bolt and snubber (16).
6. Remove tool from vise.
7. Unhook two closing springs (15).
8. Remove bolt (19) and nut (20) and snubber (16).
9. Remove cutterhead from handles using 9/16" wrenches.
10. Remove right handle assembly, with the chain and spring still attached, from the left handle.
11. Remove retaining ring (54) from sprocket pin (51).
12. Remove sprocket pin (51).
13. Remove 2 side plates (55), sprocket (56), washer (57), pin (23), detent pawl (28), and spring (36).
14. Clean all parts thoroughly with solvent.

Maintenance (cont'd)

Assembly

1. Assemble sprocket pin (51) to one side plate (55). Lay this assembly on the bench with the notched edge of the plate nearest you (see Figure 3).




Figure 3

2. Apply a light film of grease to the shank of the pin.
3. Slide sprocket (56) onto pin.
4. Apply grease to the detent pin (23) and slide into the detent pawl. Place the detent spring (36) onto the pin making sure the spring ends have not been bent out of shape. The cross arm of the spring goes under the flat side of the arrow shaped point of the detent pawl (see Figure 2).
5. Assemble one end of detent pin (23) into the hole on side plate (55) and engage the rounded end of the sprocket (56) (see Figure 3).




Figure 4

6. Match up the second plate (55) with the first, and place over the detent pin and pivot bolt. Do not insert spring ends into plates at this point (see Figure 4).
7. Hold the left handle (53) in vise with the drive pawl facing up and the handle pointing to your left (see Figure 5). Pull the drive pawl up, moving counter-clockwise, and insert a 1/8" pin (rod or nail) through the small holes in the plates near the drive pawl to hold it in a horizontal position (see Figure 5).
8. Grasp the side plate assembly firmly with the notched edges of the plate facing down. While holding tightly between fingers, remove the sprocket pin (see Figure 6).
9. Carefully insert the plate assembly into the left handle between the washers (57). Align the holes and slide the sprocket pin into position.




Figure 5




Figure 6

10. Secure sprocket pin with retaining rings (54). (This assembly must be free to pivot freely.)
11. With a small hook tool, reach up from the bottom of the assembly, between the plates and hook the ends of the detent spring into their respective holes (see Figure 7). Check to be sure spring loops are not caught between the pin and the side plate.
12. Remove the 1/8" pin from under the pawl and engage the drive pawl with sprocket (56).
13. Remove the handle from the vise.
14. Hook the longer loop on the chain spring (39) onto the free end of the chain (38). Lay the left and right handles on the bench. The drive pawl is located in the left handle. The chain is attached to the right handle. Feed the spring on the chain over the sprocket and into the left handle (see Figure 9).





Figure 7



Figure 8

Maintenance (cont'd)

15. With handles remaining in this position, assemble the cutting head to the left handle. The thick spacer (25) goes between the blade holders (see Figure 9). Use the longer bolt (12) and nut (26) and tighten securely.

**Figure 9**


16. Assemble the other side of the head to the right handle using bolts (12), nuts (26) and washer (7). Tighten securely.
17. Hook open end of closing spring (15) into holes in handle (53) so that closed loops will be against side plates (55).
18. Insert bolt (19) through closed loop on one of the springs (15) and insert through 1/4 inch hole in side plate (55). At the same time assemble snubber (16) and slide bolt through snubber.
19. Assemble other spring (15) onto bolt and assemble nut onto bolt.
20. Tighten nut approximately one thread beyond end of bolt.
21. Hook the chain spring (39) over pin at end of the left handle (see Figure 10).
22. Assemble snubber (16) and bolt (19) to handle. Assemble nut and tighten so as not to bind assembly (see Figure 11).

**Figure 10****Figure 11**

23. Check operation of the tool by opening and closing. If operation is satisfactory, proceed to next step.
24. Assemble grip to left handle (53). There is a "key" in the interior of the grip. Align this key with the slot in the left (or ratcheting) handle, and push the grip over the handle. No lubrication or adhesive is needed. Assemble clamp to grip and tighten.

If sliding a replacement grip over a replacement right handle (31), spread a small amount of soapy water over the handle to ease assembly. It will eventually dry out and allow a solid adhesion to the handle. The grip requires pounding to fit over the handle.

Illustration



Parts List

756 (for serial codes after ZDHA)

Key	Part No.	Description	Qty
2		Blade (included in 50341880 kit)	2
4		Bolt, 1/2-20 x 1-1/4 pivot.....	1
5		Nut, 1/2-20 hex slotted.....	1
6		Pin, ø3/32 x 3/4 drive.....	1
12		Screw, 3/8-24 x 1-1/2 hex head cap	4
15		Spring, extension	2
16		Snubber, chain	2
19		Screw, 1/4-20 x 1-3/4 socket head cap (order with item 20).....	2
20		Nut, 1/4-20 hex lock (order with item 19)	2
23	50341677	Pin, detent.....	1
24		Spacer, thin	2
25	50341693	Spacer.....	2
26		Nut, 3/8-24 hex lock	4
28	50341650	Pawl, detent	1
29	90527879	Link, chain connector (included with item 38)	
30	50341596	Bushing	1
31	50362119	Right handle unit (includes items 31A, 31B, 43)	1
31A	50021621	Decal, identification, Model 756	1
31B	50021630	Decal, warning	1
33	50341758	Spring, drive pawl	1
34	50341642	Pawl, drive.....	1
36	50341766	Spring, torsion.....	1
37		Ring, retainer.....	4
38	50341723	Chain (includes item 24).....	1
39	50341774	Spring, chain.....	1
40		Rollpin, ø1/8 x 1-1/8	1
43	50340832	Grip, handle.....	2
51		Pin, sprocket.....	1
52		Pin, pawl drive.....	1
53		Handle, left.....	1
54		Ring, retaining	2
55		Side plate	2
56		Sprocket.....	1
57		Washer, 5/8 flat	2

Repair Parts List

756 (for serial codes after ZDHA)

Key	Part No.	Description
1	50341880	756 cutterhead (includes items 2, 4, 5, 6, 12, 24, 26) Recommend replacing pivot bolt and nut whenever blades are replaced
13	50341898	756 and 757 repair kit (includes items 15, 16, 19, 20)
47*		Nut, 7/16-20 hex slotted
48*		Bolt, 7/16-20 x 1-1/8 hex head
50	50356410	756 pivot bolt assembly (includes items 4, 5, 6, 47, 48)

*Use 7/16" bolt and nut only with 5/16" thick blades (earlier model)

Ratchet Mechanism Upgrade Kit

756 (upgrades ratchet mechanism on cutters with no serial code)

Key	Part No.	Description
58	50372327	Ratchet mechanism (includes items 37, 51, 52, 53, 54, 55, 56, 57)

Parts List
757 (for serial codes after ZDHA)

Key	Part No.	Description	Qty
4		Bolt, 1/2-20 x 1-1/4 pivot.....	1
5		Nut, 1/2-20 hex slotted.....	1
6		Pin, ø3/32 x 3/4 drive.....	1
8		Blade unit (included in 50341871 kit).....	2
10		Keeper unit.....	1
11		Screw, 5/16-18 x 1/2 hex cap.....	2
12		Screw, 3/8-24 x 1-1/2 hex head cap.....	4
15		Spring, extension.....	2
16		Snubber, chain.....	2
19		Screw, 1/4-20 x 1-3/4 socket head cap (order with item 20).....	2
20		Nut, 1/4-20 hex lock (order with item 19).....	2
23	50341677	Pin, detent.....	1
24		Spacer, thin.....	2
25	50341693	Spacer.....	2
26		Nut, 3/8-24 hex lock.....	4
28	50341650	Pawl, detent.....	1
29	90527879	Link, chain connector (included with item 38)	
30	50341596	Bushing.....	1
31	50362119	Right handle unit (includes items 31A, 31B, 43).....	1
31A	50021648	Decal, identification, Model 757.....	1
31B	50021630	Decal, warning.....	1
33	50341758	Spring, drive pawl.....	1
34	50341642	Pawl, drive.....	1
36	50341766	Spring, torsion.....	1
37		Ring, retainer.....	4
38	50341723	Chain (includes item 29).....	1
39	50341774	Spring, chain.....	1
40		Rollpin, ø1/8 x 1-1/8.....	1
43	50340832	Grip, handle.....	2
46		Washer, 5/16 int. tooth lock.....	2
51		Pin, sprocket.....	1
52		Pin, pawl drive.....	1
53		Handle, left.....	1
54		Ring, retaining.....	2
55		Side plate.....	2
56		Sprocket.....	1
57		Washer, 5/8 flat.....	2
59		Pin, ø5/16 x 3/4 stop.....	1

Repair Parts List

757 (for serial codes after ZDHA)

Key	Part No.	Description
7	50341871	757 cutterhead (includes items 4, 5, 6, 8, 10, 11, 12, 24, 46, 59)
13	50341898	756 and 757 repair kit (includes items 15, 16, 19, 20)
49*		Washer, 1/2 flat
50	50356410	757 pivot bolt assembly (includes items 4, 5, 6, 49)

*Use washer with 5/16" thick blades (earlier model)

Ratchet Mechanism Upgrade Kit

757 (upgrades ratchet mechanism on cutters with no serial code)

Key	Part No.	Description
58	50372327	Ratchet mechanism (includes items 37, 51, 52, 53, 54, 55, 56, 57)