



"SERIES THREE"

480 VOLT 3 PHASE DELTA ELECTRIC INSTANTANEOUS WATER HEATER

INSTALLATION AND OWNERS MANUAL

WARNING

BEFORE ATTEMPTING INSTALLATION OF THIS UNIT OR MAKING ANY ADJUSTMENTS TO THE UNIT ALWAYS BE SURE MAIN CIRCUIT BREAKER IS OFF TO PREVENT DANGER OF SERIOUS ELECTRIC SHOCK.

INSTALLER/ CONSUMER RESPONSIBILITIES

PLEASE TAKE THE TIME TO READ NOT ONLY THIS MANUAL BUT ALSO THE WARRANTY CARD ENCLOSED. WARRANTY OF THIS HEATER WILL DEPEND ON PROPER INSTALLATION, OPERATION, AND REQUIRED MAINTENANCE. THE WARRANTY SHALL BE VOID IF THE DESIGN OR STRUCTURE OF THE WATER HEATER HAS BEEN ALTERED IN ANY WAY WHATSOEVER. THE MANUFACTURER OF THIS WATER HEATER WILL NOT BE LIABLE FOR ANY DAMAGES BECAUSE OF FAILURE TO COMPLY WITH THE INSTALLATION AND OPERATING INSTRUCTIONS OUTLINED ON THE FOLLOWING PAGES.

IF YOU REQUIRE ANY HELP OR HAVE ANY QUESTIONS RELATING TO THE INSTALLATION OR PERFORMANCE OF THIS HEATER, PLEASE CALL OUR TECHNICAL SERVICE DEPARTMENT:

203-267-7890 or 800-543-6163

HAVE THE INFORMATION LISTED BELOW BEFORE CALLING.

MODEL : _____ ELEMENT RESISTANCE: _____ OHMS

SERIAL NO : _____ SWITCH ON FLOW RATE: _____ GPM

INSTALLATION DATE : _____ OPERATING TEMPERATURE
MIN: _____ MAX: _____

MODEL NUMBERS COVERED

Model Number	Volts (delta) 3 wire	Max . Output @ 480V	Amps Per phase
ED020480T2T, T3, T3 EE	480	20kW	24
ED024480T2T, T3, T3 EE	480	24kW	29
ED032480T2T, T3, T3 EE	480	32kW	35.5

Unless otherwise noted, all above units have the following flow rate and temperature specifications as factory standard settings:

FLOW RATES

T2T: Turn-on 0.7 GPM / Maximum 4 GPM
T3 EE: Turn-on 0.95 GPM / Maximum 6 GPM
T3: Turn-on 1.8 GPM / Maximum 6 GPM

TEMPERATURE

T2T and T3: Standard preset 140 degrees F
T3 EE: Standard preset 90 degrees F

T2T OPTIONS:

S: Sanitation (Temperature - 180 degrees)
ML: Multi-lav (0.3 gpm activation, temperature set at 110 degrees)
FS: Factory Set (Temperature: Customer specified from Ambient to 180 degrees)

GENERAL

To obtain optimum performance and energy savings from your Eemax heater, the unit should be located as near as possible to the point of use. The unit must only be installed in a vertical position with the inlet and outlet at the bottom.

The power is activated by individual electronic flow switches located in each of the three heating modules. These modules will be damaged by excessive heat; **do not** solder any pipes that are in contact with the heater.

Also ensure pipes are clear of installation debris before fitting the heater, otherwise the flow switches could jam in the “on” position. The unit must be connected to its own individual electric circuit protected by a suitably rated three pole breaker. The maximum voltage which can be applied across any heating module is 480 volts.

WARNING

Improper installation, adjustment, alteration, service or maintenance can cause DEATH, SERIOUS BODILY INJURY OR PROPERTY DAMAGE. Refer to this manual for assistance or consult the local electric utility for further information.

The unit is supplied with 1/2” compression water fittings.

Under no circumstances use a propane or plumber’s torch on pipe which is connected to the heater, as serious damage to the electronic flow switch will result. **Do not use pipe dope.**

WARNING

Failure to ground the system may result in death or serious injury.

MOUNTING THE UNIT

- 1) The unit should be mounted as close to the point of use as possible.
- 2) This unit must only be mounted in the vertical position with the water fittings located at the bottom of the unit. Mounting other than in the vertical position WILL cause element burn out.
- 3) The cold water inlet is on the right hand side and the hot water outlet is on the left hand side. Under NO circumstances can these be reversed.
- 4) Leave a minimum of 8" above the unit for easy replacement of the elements.
- 5) The heater should be fixed to the wall using all 4 mounting holes of the back plate. Unit weight is approximately 15 lbs. Use an appropriate fastener for this weight. For the unit to be mounted against hollow walls, suggest using steel wall anchors with the correct grip range and #6-32 screw size minimum.
- 6) The unit should be installed in the plumbing system in such a way that there is no tendency for the unit to be starved of water. For example: an excessive draw-off of cold water just before the unit. Also do not fit an unrestricted hot water draw-off point below the heater as this will tend to empty the heater by siphoning.

NOTE

ALL MOUNTING AND PLUMBING MUST BE COMPLETE BEFORE YOU PROCEED WITH ELECTRICAL HOOK-UP. TEST THE INSTALLATION FOR LEAKS BEFORE CONNECTING THE ELECTRICAL SUPPLY.


PLUMBING HOOK-UP

- 1) The unit is supplied with $\frac{1}{2}$ " compression fittings. DO NOT USE PIPE DOPE AND DO NOT SOLDER PIPE TO THE INLET OR OUTLET.
- 2) Take care to ensure that the pipes are correctly aligned with the inlet and outlet bosses in order to avoid excessive stress on the heater manifold.

NOTE: When soldering pipe joints remove heater from the wall. Serious damage can occur if any soldering is done while pipes are connected to the heater.

Run water through the supply pipe to remove all debris from the pipe before connecting the heater. Failure to do so could cause damage to the flow switch.

- 3) Install isolating valves (full flow ball valve type) on **both** inlet and outlet pipes. This allows unit to be isolated for maintenance purposes.
- 4) When all plumbing is complete, fully check the system for water leaks at all plumbing connections. If leak is present take corrective action. Fully open both inlet and outlet ball valves. Run all hot water outlets fed by this heater one at a time for a minute or two until the water flow is continuous, free from "gulping" and from all visible air pockets.



NOTE

ALL MOUNTING AND PLUMBING MUST BE COMPLETE BEFORE YOU PROCEED WITH ELECTRICAL HOOK-UP.

TEST THE INSTALLATION FOR LEAKS BEFORE CONNECTING THE ELECTRICAL SUPPLY.

ELECTRICAL HOOK-UP

WARNING

HAZARD OF ELECTRICAL SHOCK! BEFORE BEGINNING ANY WORK ON THE INSTALLATION, MAKE SURE THE ELECTRICAL SUPPLY TO THE HEATER IS TURNED "OFF". FAILURE TO DO THIS COULD RESULT IN DEATH, SERIOUS BODILY INJURY, OR PROPERTY DAMAGE.

WARNING

WATER HEATERS EQUIPPED FOR ONE VOLTAGE ONLY: CHECK THE RATING PLATE ON THE FRONT OF THE UNIT. DO NOT USE THIS WATER HEATER WITH ANY VOLTAGE OTHER THAN THE ONE SHOWN ON THE MODEL RATING PLATE. FAILURE TO DO SO CAN RESULT IN DEATH, SERIOUS BODILY INJURY, OR PROPERTY DAMAGE. IF YOU HAVE ANY QUESTIONS OR DOUBTS CONSULT YOUR ELECTRIC COMPANY.

This heater must have its own independent circuit using four wires; three live and one earth ground, of the appropriate rating protected by the correctly rated three pole breaker

RATINGS OF "ED" Series Three Electric Tankless Water Heater

			Temperature Rise (F°) GPM (gallons per minute)				
Model number prefix	kW Rating	Amps per phase	2 gpm	3 gpm	4 gpm	T3 and T3 EE Only 5 gpm	T3 and T3 EE Only 6 gpm
ED020	20	24	68	46	34	27	23
ED024	24	29	82	55	41	33	27
ED032	32	35.5	110	73	55	43	36

THIS UNIT MUST **NOT** BE CONNECTED IN STAR CONFIGURATION

WARNING

FAILURE TO GROUND THE SYSTEM MAY RESULT IN DEATH OR SERIOUS INJURY

COMMISSIONING YOUR HEATER

IMPORTANT

Before switching “on” the power at the main circuit breaker panel make sure that the hot water circuit is free of air pockets or premature failure of the heating element will occur. To do this open all hot water fixtures one at a time for several minutes until the water flow is continuous and free from “gulping” and from visible air pockets.

- 1) With inlet and outlet BALL VALVES fully open, turn on a hot water outlet.
- 2) Run for 3 minutes.
- 3) Switch on electric supply at circuit breaker panel.
- 4) The power indicator lights should now come on.

NOTE: At this point water temperature may not be hot. “EE” units are preset to deliver tepid water only.

- 5) Using the OUTLET BALL VALVE slowly reduce water flow until desired temperature is achieved at hot water outlet.

NOTE: The water temperature is regulated by the flow through the heater. The lower the flow the higher the temperature and vice versa.

- 6) If water does not achieve desired temperature, please call technical services.

TROUBLESHOOTING

SYMPTOM: NO HEAT - INDICATOR LIGHT OFF

1) ELECTRIC SUPPLY IS OFF

Turn on the main circuit breaker.

2) NO OR LOW WATER FLOW

Ensure that the minimum flow rate to turn on your heater is met, for this figure refer to page 2 of this manual.

Also check that the inlet filter screen is clear from any debris.

3) WATER CONNECTIONS ARE REVERSED

Cold water inlet = right side, hot water outlet = left side.

4) ELEMENT BURNED OUT

TURN OFF THE MAIN BREAKER!

Using an ohmmeter test the resistance of the heating element across the two threaded termination rods on top of the element.

See the front cover of this manual for the correct value.

If the resistance is much greater than the correct value, call your supplier for a replacement element.

SYMPTOM: NO HEAT OR LOW TEMPERATURE WITH INDICATOR LIGHT ON

1) WATER FLOW TOO HIGH

Reduce the water flow by using an outlet ball valve. See page 6 for temperature rise at various flow rates.

2) INCORRECT POWER SUPPLY

Make sure that the unit is connected to the voltage supply specified on the rating label on the front cover of the unit and no other.

3) ELEMENT BURNED OUT

TURN OFF THE MAIN BREAKER!

Repeat the steps from paragraph 4 above.

4) THERMOSTAT ADJUSTMENT SCREW NOT TURNED UP

Turn the thermostat adjustment screw clockwise in small increments until the indicator light remains on. Take care not to force the screw past its stop position.

REPLACEMENT PARTS DIAGRAM

HEATER CORE ASSEMBLY (PLEASE SPECIFY 480 VOLTS ON ANY ORDERS)

FOR ED020 PART# EX3454

FOR ED024 PART# EX2880

FOR ED032 PART# EX2194

