# Schedule 40



Not Shown: Half Kits (No Tee or Pipe)

Model 901:	Stoppers, Knobs, Strainer Bodies determined by type of tub closure, i.e., Lift and Turn, etc.
Model 921-PP:	ABS Stopper, Plastic Knob,
	Brass Strainer Body, Chrome PP only
Model 951-PP:	ABS Stopper, Plastic Knob,
	Zinc Strainer Body, Chrome PP only

PRESFLO<sup>®</sup> (PF)

Foot Actuated (FA) only

रू ADA





Includes built-in test membrane

Easily remove membrane after test

Snap-on overflow plate. No screws

See price list for complete item numbers and available options.

When ordering, please specify complete item number and any applicable option codes.



For More Information Contact: WATCO Manufacturing Company 1220 South Powell Road Independence, MO 64057-2724 B Ph. 816-796-3900 • FAX 816-796-0875 Always a step ahead www.watcomfg.com

© 2020 WATCO Mfg. Co.

Designs and dimensions of product are subject to change without notice.

10

# Innovator<sup>®</sup> 900/901

Stoppers, Knobs, and Bodies determined by tub closure selected

# Innovator<sup>®</sup> 920/921

ABS Plastic Stopper, Plastic Knob, Brass Body, **Chrome PP only** 

# Innovator® 951 Half Kit

ABS Plastic Stopper, Plastic Knob, Zinc Body, Chrome **PP** only

## Sturdy 1.5" Schedule 40 PVC or ABS **Solvent Weld Assembly**

### **SPECIFICATIONS**

#### **FEATURES:**

- · Eliminates all screws
- Eliminates need for separate overflow test plug
- Eliminates leaks due to loose overflow attachment
- · Eliminates dual inventory of one- and two-hole overflow plates

#### APPROVALS (900/901 models):

 Manufactured in compliance with ASME A112.18.2-2005/CSA B125.2-2005.

#### **PATENTS** (Innovator®):

https://www.watcomfg.com/patents

### **THREADS (Strainer Body and Drain Elbow):**

- 1<sup>1</sup>/<sub>2</sub>" 11<sup>1</sup>/<sub>2</sub> NPSM (Coarse Thread)
- 1.865" Major Diameter (outside thread diameter)
- 11.5 threads per inch

#### D PVC PIPING: □ ABS ROUGH-IN (RI's) and STOPPER/FACEPLATE (SF's)

### STOPPER/FACEPLATE'S

(example: 900-PPSF-0-CP) Overflow plate and





### **ROUGH-IN'S**

stopper assembly

(example: 900-PPRI-PVC-CP)

All parts, including strainer body, except the overflow plate and stopper assembly