

# Duraflex Products

## Laundry Pan

### Installation Instructions

#### **Pre-installation preparations:**

Drain assembly fits inside a 2" pipe.

Make sure pipe is plumb before cutting, if not plumb, then the pipe needs to be corrected, and made plumb.

Cut the pipe so that it is flush with the floor. Ideally use an undercut saw. Pipe should make contact with bottom of pan.

Scrape and clean the floor where the pan will be placed so that it is smooth and free of loose debris.

#### **How to mark pan for hole.**

Place a piece of tape over the center of the drain. Something that will allow you to see the center hole of the drain will work best. Place a small dab of adhesive, approximately the size of a pin head, over the center hole of the drain on the tape. Lay pan over the drain. Remove pan and drill where the pan is marked with a 2" hole saw.

Remove drain from pipe and remove tape from drain cover.

#### **Installation of pan.**

Dry fit pan, and install drain cover into hole of pan, and into drain pipe. Check to make sure everything fits correctly and in the desired location. Check if pipe makes contact with bottom of pan.

Apply adhesive to bottom of pan.

Apply ABS weld to bottom of pan where pipe will attach to pan.

Apply ABS weld to top of drain pipe.

Place pan on floor, and press firmly in all areas to ensure pan lies flat and adhesive is making contact with the floor and the drain pipe.

Place drain assembly into drain pipe.

[www.Duraflexproducts.com](http://www.Duraflexproducts.com)

Phone - 801-377-6887

Fax – 801-377-6891