

# C Cutters Instructions

03404, 03405, 03406, 03407, 03408, 03409

Snap the cutter onto the copper tubing in the location where cut is desired. Turn the spring-loaded tubing cutter in the direction of the arrows etched onto the tool. This permits the springs on the cutter wheel to tighten with each rotation around the pipe. Turn until cut is complete.

Replacement Cutter Wheel: #03375 SLRCW

Each cutter fits just one size of tubing:  $\frac{1}{2}$ ",  $\frac{3}{4}$ ", or 1"

**Reed Manufacturing Company**  
1425 West 8th Street, Erie, PA 16502 USA  
Phone: 800-666-3691 or 814-452-3691  
Fax: 800-456-1697 or 814-455-1697  
[www.reedmfgco.com](http://www.reedmfgco.com)



3/2013