

Nulone

Door Chime Pushbutton & Wiring Sleeve

MODELS: PB-41 & PB-41L

- 1. Refer to Figure 1. The wiring sleeve has wall thickness indicators on the side of the barrel.
- 2. Refer to Figure 2. Determine finished wall thickness and mount wiring sleeve to stud by lining up proper indicator mark with front edge of stud.
- 3. Run pushbutton wires to location, pull wires through sleeve, and twist around the retainer. Close wiring sleeve cover.
- 4. After finished wall is constructed, open wiring sleeve cover, remove wiring from retainer, and pull cover off to discard.
- 5. Refer to Figure 3. Strip 1/4" insulation from wires. Push wire ends into grooves behind terminal plates and tighten screws. Position pushbutton in hole and mount escutcheon with the screws provided. NOTE: Models PB-41B and PB-41LB do not





WARRANTY OWNER: NuTone warrants to the original consumer purchaser of its products that such products will be free from defects in materials or workmanship for a period of one (1) year from the date of original purchase. THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

During this one year period, NuTone will, at its option, repair or replace, without charge, any product or part which is found to be defective under normal use and service. THIS WARRANTY DOES NOT EXTEND TO FLUORESCENT LAMP STARTERS OR TUBES, FILTERS, DUCT, ROOF CAPS, WALL CAPS AND OTHER ACCESSORIES FOR DUCTING. This warranty does not cover (a) normal maintenance and service or (b) any products or parts which have been subject to misuse, negligence, accident, improper maintenance or repair (other than by NuTone), faulty installation or installation contrary to recommended installation instructions

The duration of any implied warranty is limited to the one year period as specified for the express warranty. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

NUTONE'S OBLIGATION TO REPAIR OR REPLACE, AT NUTONE'S OPTION, SHALL BE THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY. NUTONE SHALL NOT BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH PRODUCT USE OR PERFORMANCE. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. This warranty supersedes all prior warranties

WARRANTY SERVICE: To qualify for warranty service, you must (a) notify NuTone at the address stated below or telephone 1/800-543-8687, (b) give the model number and part identification and (c) describe the nature of any defect in the product or part. At the time of requesting warranty service, you must present evidence of the original purchase date

Date of Installation

Builder or Installer

Rev. 03/2001

Model No. and Product Description


IF YOU NEED ASSISTANCE OR SERVICE:


For the location of your nearest NuTone Independent Authorized Service Center: Residents of the contiguous United States Dial Free 1-800-543-8687 Please be prepared to provide:


Product model number . Date and Proof of purchase . The nature of the difficulty Residents of Alaska or Hawaii should write to: NuTone Inc. Attn: Department of National Field Service, 4820 Red Bank Road, Cincinnati Ohio 45227-1599.

Residents of Canada should write to: Broan-NuTone Canada, 1140 Tristar Drive,

Mississauga, Ontario, Canada L5T 1H9.







Product specifications subject to change without notice.

4820 Red Bank Road, Cincinnati, Ohio 45227 Printed in U.S.A., Rev. 05/01, Part No. H0713