

CODE NUMBER

3451111

DESCRIPTION

1.6 gpf, Rough Brass Finish, Fixture Connection Rear Spud, Single Flush, 11-12.75 L Dimension, Electrical Override, Hardwired, Sensor-Operated, Royal® Concealed Sensor Hardwired Water Closet Flushometer

DETAILS

• Flush Volume: 1.6 gpf (6.0 Lpf) • Finish: Rough Brass (RB) Power Type: Hardwired (HW)

• Valve: Diaphragm

• Valve Body Material: Semi-red Brass

• Fixture Type: Water Closet • Fixture Connection: Rear Spud

• Rough-In Dimension: 14 ½" (368mm)

• Spud Coupling: 1 1/2" (38mm) • Supply Pipe: 1" (25mm)

• L Dimension: 11"-12 3/4" (279-324mm) (11-12-3/4-LDIM)

Override: Electrical (OR)

FEATURES

- PERMEX® Synthetic Rubber Diaphragm with Dual Filtered Fixed **Bypass**
- User friendly three (3) second Flush Delay
- OPTIMA® EL-1500 Self-Adaptive Infrared Sensor with Indicator Light
- Die Cast Sensor Plate with no visible Fasteners (for 2-gang Electrical Box)
- Non-Hold-Open Integral Solenoid Operator, Fixed Metering Bypass and No External Volume Adjustment to Ensure Water Conservation
- High Back Pressure Vacuum Breaker Flush Connection, Spud Coupling and Flanges for 11/2" Exposed Back Spud
- Stop Seat and Vacuum Breaker molded from PERMEX® Rubber Compound for Chloramine Resistance
- 1" I.P.S. Wheel Handle Bak-Chek® Angle Stop
- Courtesy Flush® Override Button

VIDEOS



ESS Flushometer



COMPLIANCES & CERTIFICATIONS









(ADA Compliant, cUPC Certified, BAA Compliant, UL Certified)

RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

ELECTRICAL SPECIFICATIONS

• Arming Delay: 16 seconds

Control Circuit: Solid State/24 VAC Input/24 VAC Output

Flush Delay: 3s

• Self-Adaptive Window: ±10

• Sensor Range: 22"-42" (559-1,067mm)

Solenoid Operator: 24 VAC

• Transformers: 0 0345154

0345999

VALVE OPERATING PRESSURE (FLOWING)

15-80 PSI (103-552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

DOWNLOADS

- Optima Sensor Activated Royal Installation Instructions
- Royal 140/152/153/195 ESS TMO SWB Installation Instructions
- Royal 152/195 ESS TMO Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Optima ESS Repair and Maintenance Guide
- Optima TMO Repair and Maintenance Guide
- Additional Downloads

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com



NOTES

All information contained within this document subject to change without notice.

Looking for other variations of the ROYAL 140 ESS product? View the general spec sheet with all options.

Find a compatible urinal for this flushometer. Find a compatible water closet for this flushometer.

ROUGH-IN

