




## Model XRV01, XRV01Z Parts List

A = Standard Equipment

O= Circuit Diagram

| Item# | Part#        | Description           | Q'ty | Unit        |
|-------|--------------|-----------------------|------|-------------|
| 001   | 850D50-7     | XRV01 NAME PLATE      | 1    |             |
| 002   | 266045-0     | TAPPING SCREW 4X20    | 9    | PC.         |
| 003   | 187974-3     | HOUSING SET           | 1    |             |
| 003   | C10 802J50-9 | CAUTION LABEL         | 1    |             |
| 003   | D10          | INC. 29               | 0    |             |
| 004   | 643843-3     | TERMINAL              | 1    | PC.         |
| 005   | 650580-2     | SWITCH SGE120C-4      | 1    | PC.         |
| 006   | 231298-0     | COMPRESSION SPRING 6  | 1    | PC.         |
| 007   | 419511-8     | SWITCH LEVER          | 1    | PC.         |
| 008   | 421961-5     | WATERPROOF COVER      | 1    | PC.         |
| 009   | 322935-8     | CAP                   | 1    | PC.         |
| 010   | 961002-0     | RETAINING RING S-6    | 1    | PC.         |
| 011   | 210018-5     | BALL BEARING 626      | 1    | PC.         |
| 012   | 210018-5     | BALL BEARING 626      | 1    | PC.         |
| 013   | 331503-6     | PIPE 25               | 1    | PC.         |
| 014   | 322934-0     | UNBALANCER            | 1    | PC.         |
| 015   | 211016-2     | BALL BEARING 626LLB   | 1    | PC.         |
| 016   | 211016-2     | BALL BEARING 626LLB   | 1    | PC.         |
| 017   | 421578-4     | RUBBER RING           | 1    | PC.         |
| 018   | 443101-5     | FELT RING             | 1    | PC.         |
| 019   | 326203-1     | JOINT                 | 1    | PC.         |
| 020   | 163534-5     | FLEXIBLE WIRE         | 1    | PC.         |
| 021   | 416244-6     | NUT 36                | 1    | PC.         |
| 022   | 163537-9     | FLEXIBLE HOSE         | 1    | PC.         |
| 023   | 266045-0     | TAPPING SCREW 4X20    | 4    | PC.         |
| 024   | 316893-8     | BEARING BOX           | 1    | PC.         |
| 025   | 211056-0     | BALL BEARING 629LLB   | 1    | PC.         |
| 026   | 911118-1     | PAN HEAD SCREW M4X12  | 2    | PC.         |
| 027   | 318038-4     | SUPPORTER             | 1    | PC.         |
| 028   | 629836-4     | DC MOTOR              | 1    | PC.         |
| 029   | 187974-3     | HOUSING SET           | 1    |             |
| 029   | C10 802J50-9 | CAUTION LABEL         | 1    |             |
| 029   | D10          | INC. 3                |      |             |
| 030   | 154948-9     | COVER COMPLETE        | 1    | PC.         |
| 030   | C10 810195-9 | CAUTION LABEL         | 1    | PC.         |
| 031   | 126206-3     | FLEXIBLE ASSEMBLY     | 1    |             |
| 031   | D10          | INC. 9-20,22          |      |             |
| A01   | ***DC18RC    | DC18RC FAST CHARGER   | 1    | PC. (XRV01) |
| A02   | BL1830       | BATTERY BL1830 SET    | 2    | SET (XRV01) |
| A03   | 141481-0     | PLASTIC CARRYING CASE | 1    | PC. (XRV01) |
| A03   | C10 417383-5 | LATCH                 | 2    | PC. (XRV01) |
| A04   | 450128-8     | BATTERY COVER         | 1    | PC. (XRV01) |
| D01   | 652008-6     | PAN HEAD SCREW M3.5X7 | 2    | PC.         |
| D02   | 654086-2     | RECEPTACLE            | 2    | PC.         |
| D03   | 654117-7     | INSULATING TERMINAL   | 2    | PC.         |
| D04   | 654199-9     | RECEPTACLE            | 2    | PC.         |