

DIAGNOSTICS, INSPECTION & LOCATING

NaviTrack® Transmitters



Remote Transmitter (512 Hz Sonde)

- Can be attached to a drain cleaning cable or a water jet hose to locate the Remote Transmitter in a line.
- Flashing LED indicates that sonde is transmitting.
- Meets FCC Class B and EN 55022 Class B requirements.

| Catalog No. | Description | Weight | |
|-------------|-----------------------------|--------|------|
| | | lb. | kg |
| 16728 | Remote Transmitter, 512-AAA | 0.4 | 0.18 |

Accessories

| Catalog No. | Description |
|-------------|--|
| 19258 | Adapter for 1 1/4" (32 mm) Sectional Cable |
| 19263 | Adapter for 5/8" & 3/4" (16 mm & 20 mm) Drum Machine Cables |
| 19268 | Adapter for 7/8" (22 mm) Sec. & 1/2" (12 mm) Drum Machine Cables |
| 19273 | Adapter for 5/8" (16 mm) Sec. & 3/8" (10 mm) Drum Machine Cables |



Floating Transmitter

Floating Transmitters are used for locating underground structures like septic tanks.

- Ideal for locating septic tanks.
- 512 Hz signal.
- Flashing LED indicates that sonde is transmitting.
- Flushable.
- Battery-powered.
- Meets FCC Class B and EN 55022 Class B requirements.

| Catalog No. | Description | Weight | |
|-------------|-------------------------------------|--------|------|
| | | lb. | kg |
| 19793 | Float Sondes (2),Plus Extra Battery | 0.4 | 0.18 |