


FORSAIRE™ COUNTERFLOW TOP VENT FURNACE

CONTROL ASSEMBLY REPLACEMENT PARTS 350 MODELS **INTERMITTENT IGNITION**


MODEL NUMBERS			
NATURAL		PROPANE	
3508232		3508231	
REF. NO.	REPLACEMENT PART DESCRIPTION	3508232	3508231
1	Valve, Natural Gas	P323210	–
	Valve, Liquid Propane Gas	–	P322044
2	Manifold	P323657	P323657
3	Orifice Fitting, Specify Model & Gas Type	P090536	P090550
4	Pilot, Natural Gas	P323418	–
	Pilot, Liquid Propane Gas	–	P323419
5	Thermocouple	–	–
	Flame Sensor	P271100	P271100
6	50mm BURNER	P323648	P323648
7	Ignition Control Unit	P321900	P321900
8	Wire Assembly	P321935/35A	P321935/35A
9	Ignition Control Wires	31B036	31B036
10	Manifold Adapter	P321887	P321887
11	Ignition Shield	11B155	11B155
12	Front Burner Bracket	9B234	9B234



FORSAIRE™ COUNTERFLOW TOP VENT FURNACE

CONTROL ASSEMBLY REPLACEMENT PARTS 500 / 650 MODELS **INTERMITTENT IGNITION**


MODEL NUMBERS			
NATURAL		PROPANE	
5508232		5508231	
REF. NO.	REPLACEMENT PARTS DESCRIPTION	5508232	5508231
1	Manifold	P323656	P323656
2	Orifice Fitting, Specify Model and Gas (2 Req.)	P332622	P332620
3	Valve, Natural Gas	P323210	–
	Valve, Liquid Propane Gas	–	P322044
4	Thermocouple	P322042	–
	Flame Sensor	P233100	P271100
5	Pilot, Liquid Propane Gas	P323073	P322680
6	50mm Burner (with pilot bracket)	P323648	P323648
7	50mm Burner (without pilot bracket)	P323649	P323649
8	Ignition Control Unit	P321900	P321900
9	Wire Assembly	P322048/48A	P322048/48A
10	Ignition Control Wires	31B036	31B036
11	Manifold Adapter	P321887	P321887
12	Ignition Shield	11B155	11B155
13	Burner Mounting R.H. Bracket Assembly	7B187	7B187



FORSAIRE™ COUNTERFLOW DIRECT VENT FURNACE

CONTROL ASSEMBLY REPLACEMENT PARTS 400 MODELS **INTERMITTENT IGNITION**


MODEL NUMBERS			
NATURAL		PROPANE	
4007332		4007331	
REF. NO.	REPLACEMENT PART DESCRIPTION	4007332	4007331
1	Manifold	P323653	P323653
2	Manifold Gasket	P151700	P151700
3	Orifice Fitting, Specify Model & Gas	P090532	P090548
4	50mm Burner	P323648	P323648
5	Burner Pan	11B133	11B133
6	Williams Valve	P323210	P322044
7	Pilot, Natural	P323418	—
	Pilot, Propane	—	P323419
8	Thermocouple	—	—
	Flame Sensor	P271100	P271100
9	Pilot Tube Gasket	P151800	P151800
10	Pilot Tube Seal	11A41	11A41
11	Gasket - 44 inch	P101600	P101600
12	Ignition Control Unit	P321900	P321900
13	Ignition Shield	11B139	11B139
14	Manifold Adapter	P321887	P321887
NOT SHOWN	Ignition Control Wires	31B036	31B036



FORSAIRE™ COUNTERFLOW DIRECT VENT FURNACE

CONTROL ASSEMBLY REPLACEMENT PARTS 400 MODELS **STANDARD PILOT**

MODEL NUMBERS			
NATURAL		PROPANE	
4007732		4007731	
REF. NO.	REPLACEMENT PART DESCRIPTION	4007732	4007731
1	Manifold	P323653	P323653
2	Manifold Gasket	P151700	P151700
3	Orifice Fitting, Specify Model & Gas	P090532	P090548
4	50mm Burner	P323648	P323648
5	Burner Pan	11B133	11B133
6	Williams Valve	P323209	P322042
7	Pilot, Natural	P323418	—
	Pilot, Propane	—	P323419
8	Thermocouple	P254000	—
	Flame Sensor	—	P271100
9	Pilot Tube Gasket	P151800	P151800
10	Pilot Tube Seal	11A41	11A41
11	Gasket - 44 inch	P101600	P101600
12	Piezo Gas Lighter	P285500	—
13	Manifold Adapter	P321888	P321887
NOT SHOWN	Ignition Control Wires	—	31B036



FORSAIRE™ COUNTERFLOW DIRECT VENT FURNACE

CONTROL ASSEMBLY REPLACEMENT PARTS 550 MODELS

MODEL NUMBERS			
NATURAL		PROPANE	
5507332		5507331	
REF. NO.	REPLACEMENT PARTS DESCRIPTION	5507332	5507331
1	Manifold	P323654	P323654
2	Manifold Gasket	P151700	P151700
3	Orifice Fitting, Specify Model & Gas (2)	P090541	P332621
4	50 mm Burner (With pilot bracket)	P323648	P323648
5	50 mm Burner (Without pilot bracket)	P323649	P323649
6	Burner Pan	11B134	11B156
7	Williams Valve	P323210	P322042
8	Pilot, Natural	P323418	—
	Pilot, Propane	—	P323419
9	Thermocouple	—	P254000
	Flame Sensor	P271100	—
10	Pilot Tube Gasket	P151800	P151800
11	Pilot Tube Seal	11A41	11A41
12	Gasket - 44 inch	P101600	P101600
13	Ignition Control Unit	P321900	—
14	Ignition Shield	11B139	—
15	Manifold Adapter	P321887	P321888
NOT SHOWN	Ignition Control Wires	31B036	—