

INSTALLATION MANUAL CONCEALED SHOWER MIXER ITEM NO.: **AB5501**




Components Checking

LIST OF COMPONENTS:

Please double-check the components list hereinafter and contact us for any unconformities.


Remarks:


- 1, Without affecting their performancing, components may be changed without notice.
- 2, Drawings for reference only.




XInstallation Instructions:

- ☆ Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory.
- ☆ To avoid the faucet from jamming, do flush the water pipe before installation.
- ☆ After installation, make sure every joint safely sealed & no leaking.
- ☆ Using condition: Working pressure at 0.05-1.0MPa (including cold & hot water pressure) with applicable water temperature: 4° C- 90° C.
- ☆ Make sure to connect the hot/cold inlet pipe correctly, if standing in front,hot water pipe connecting to the left & cold water pipe connecting to the right.






※ Dimention Drawings




※Important notice:


This concealed shower mixer can be used by different assembly as the drawing shown below:


- ☆Assemble A: to overhead shower and spout with diverter;
- ☆Assemble B: to overhead shower only.





※Installation Procedures(Assembly A):














※Installation Procedures(Assembly B):





X Operation

- ☆ How to operate the mixer handle
 - 1) Raise the handle lever up for opening water, push down to close;
 - 2) Turn the handle lever to the left to increase hot water flow, to the right to lower water temperature.



XCleaning and Maintenance

- ☆ To keep the product clean, shining and in good condition, follow the steps as below:
 - 1. Flush with clean water & dry with soft cloth only;
 - 2. If any dirt, clean with soft liquid or transparent glass detergent.
 - 3. Do not use any scrubbing detergent, polisher, sand-cloth, paper tissue or scraper.
 - 4. Do not use acid detergent, indissovable grain-like detergent or soap.

