

ROUND **PATCH KIT**

Instructions

1. Buff area around injury, slightly larger than patch being used, lightly with enclosed metal buffer. Removing all loose particles and making sure entire area presents roughened appearance.
2. Squeeze moderate amount of rubber cement onto roughened surface, spread evenly, and work into material. Scrape off excess cement and allow remaining cement to dry.
3. Remove backing from patch, backing is split for easy removal. Avoid touching exposed surface.
4. Center patch over injury and press firmly into place, especially around edges. Press from inside to out to eliminate bubbles.
5. Remove remaining clear liner. Repair is now complete!

WARNING: This product contains a chemical known to the State of California to cause cancer, birth defects or reproductive harm.

DANGER: EXTREMELY FLAMMABLE – CONTAINS HEPTANE & TOLUENE. Do not use near heat or flame. Vapor harmful, do not inhale or swallow. Avoid contact with eyes and skin. For eye contact, flush with water for 15 minutes. For skin contact, wash thoroughly with soap and water. If swallowed, do not induce vomiting and get immediate medical attention. **KEEP OUT OF REACH OF CHILDREN.**