
# American Standard

## **TOWN SQUARE** ON/OFF VALVE TRIM

# Installation Instructions T555700




Certified to comply with ANSI A112.18.1M

**ASSE 1016** 

Thank you for selecting American-Standard...the benchmark of fine quality for over 100 years.


To ensure that your installation proceeds smoothly-please read these instructions carefully before you begin.

M968657 Rev.1.2



#### **Recommended Tools**







Phillips Screwdriver

#### **CARE INSTRUCTIONS:**

- To keep your new faucet looking new, please follow these simple care instructions:
  - **DO:** Simply rinse the faucet clean with clear water. ■ Dry the faucet with a soft cotton cloth.

#### DO NOT:


- Do not use any abrasive cleaners, cloths, or paper towels.
- Do not use any cleaning agents containing acids, polish abrasives, or harsh cleaners or soaps.
- Regular and routine cleaning will reduce the need for heavy cleaning and polishing. If heavy cleaning is required, the following procedures are recommended:

- Remove as much surface dirt and film using clear water and soft cotton cloth (as described above).
  - Use any of the following to remove tough surface film and build-up:
  - Mild liquid detergents
  - Clear ammonia free liquid glass cleaners
  - Non-acidic, non-abrasive gentle liquid or fully dissolved powder cleansers mixed according to manufacturers directions.
  - Non-abrasive liquid polishers
- Once clean, rinse faucet again with clear water to thoroughly remove cleaner or polish and blot dry with a soft cotton cloth.

Failure to follow these care instructions may damage the Faucet's finish.


### TRIM INSTALLATION

- Push VALVE COVER (1) over VALVE CARTRIDGE (2) until it is seated against the stop.
- Place ESCUTCHEON HOLDER (3) over VALVE COVER (1). Line up holes in ESCUTCHEON HOLDER (3) with THREADED TABS (4) on VALVE.
- Install MOUNTING SCREWS (5) through ESCUTCHEON HOLDER (3) and into THREADED TABS (4). Tighten SCREWS securely.
- Place ESCUTCHEON (6) over ESCUTCHEON HOLDER (3) and push evenly for a snap fit.



### 2 HANDLE INSTALLATION

- Install HANDLE ADAPTER (1) onto VALVE STEM (2).
- Push HANDLE BASE (3) onto HANDLE ADAPTER (1).
- Install HANDLE SCREW (4) and tighten.
- Push in INDEX CAP (5).



## 3 OPERATING THE VALVE

- Turn HANDLE into OFF position.
- Turn on water supplies, and check all connections for leaks.
- Operate HANDLE to flush water lines thoroughly.
- Turn HANDLE OFF.

