
ULTRA FAUCETS




Single lever handle Lavatory faucet


Model NO.: UF36500

UF36503 UF36505


Preparation / Assembly



Shut off water supplies. Remove old faucet. Clean sink surface in preparation for new faucet.



Screw the mounting stud into the body. Secure the faucet to sink by installing steel washer and nut onto it. Tighten with wrench.



Important: After installation is completed. Turn on water supply and allow both hot and cold water to run for at least one minute each. While water is running, check for leaks.

Reinstall Aerator. Your new faucet is now ready to use.

INSTRUCTION


Tools:

- · Adjustable Wrench
- ·Pliers
- ·Pipe Wrench
- ·Screwdriver
- · Teflon Tape




Your new lavatory faucet is designed for years of trouble-free

Keep it looking new by cleaning it periodically with a soft cloth. Avoid abrasive cleaners, steel wool and harsh chemicals as these will dull the finish and void your warranty.



Place optional Flange on bottom of new faucet before position faucet through mounting hole.



Apply pipe tape onto threads of water supplies. Use wrench when tightening the hose connection, do not overtighten.

Exploded Drawing RP(Replacement Parts) Screw Model NO.: UF36500 Temperature Indicator-UF36503 Handle UF36505 Cap **Bonnet** Cartidge Bodyaerator Flange **EVA Washer** Shank Steel Washer Mounting Nut Water Supply Hose Assembly

Limited Lifetime Warranty

Ultra Faucets warrants to the original purchaser that its products will be free from defects in workmanship and materials. All Ultra Faucets are provided with a life time limited warranty. This warranty does not cover any other labor or service charges associated with the removal, repair, or reinstallation of Ultra Faucets products. This express warranty does not apply to products that have been damaged as a result of misuse, abuse, negligence, accident, faulty installation or maintenance practices and/or used in any manner contrary to those recommended by the manufacturer.